## SPECIFICATION SHEET JFW MODEL 50PA-979 HANDOVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range 698-3000 MHz

Configuration 6 x 8 Handover System

(see block diagram 092-8473 for attenuator addressing)

(all ports are bi-directional)
(full fan-out configuration)

(the ADMIN password is located on rear panel)

Enclosure Type 19 inch rack mount @ 8RU high

Impedance 50 Ohms nominal

Attenuation Range 0-95 dB in 1 dB steps

Startup/Default States Maximum attenuation (see ATTEN STARTUP command)

(configurable) DHCP enabled (see NET command)

4 Ethernet users (see NET USERS command)

Prompts off (see PROMPT command)

All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users.

VSWR 1.7:1 maximum < 1.5:1 typical

< 1.3.1 cypica

Insertion Loss 34 dB maximum

29 dB typical @ 698 MHz 33 dB typical @ 3000 MHz

Attenuation Accuracy  $\pm$  0.50 dB 1-7 dB

 $\pm$  1.00 dB 8-11 dB  $\pm$  1.25 or 3% 12-95 dB

(whichever is greater)
(guaranteed monotonic)

Isolation 50 dB minimum (Input to Input) 50 dB minimum (Output to Output)

Switching Speed 4 microseconds typical

RF Input Power

(after command received and processed)
(3 milliseconds typical processing time)

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

+30 dBm average

RS-232 (up to 115200 Baud)

## --CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

## SPECIFICATION SHEET JFW MODEL 50PA-979 HANDOVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands

Attenuator Control Commands:

Atten, Set Path, Read Path, Read All Paths, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt

RF Connector

SMA female

Temperature Range

 $0^{\circ}C$  to  $+50^{\circ}C$ 

AC Supply

100-240 VAC @ 47-63 Hz

Physical Size

See outline drawing 092-8472

ECR/ECN #	DATE	REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
1	11/09/2015		CLK 11/09/2015				
28159 1	10/05/2017	A	CLK 10/05/2017				

Page 2 of 2 JFW FORM E-7-F REV F