#### SPECIFICATION SHEET

JFW MODEL 50BA-045-63

## BENCHTOP PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range	100 MHz-18 GHz
Configuration	Four solid-state programmable attenuators
Enclosure Type	Mini-benchtop
Impedance	50 Ohms nominal
Attenuation Range	0-63 dB in 0.5 dB steps
Startup/Default States (configurable)	Maximum attenuation (see ATTEN STARTUP command) DHCP enabled (see NET command) 4 Ethernet users (see NET USERS command) Prompts off (see PROMPT command) Jog speed 5 (see JOG SPEED command)
VSWR	2.2:1 maximum < 1.4:1 typical 0.1-6 GHz < 1.8:1 typical 6-18 GHz
Attenuation Accuracy	<pre>± 0.3 dB 0.5-3.5 dB ± 0.6 dB 4-14.5 dB ± 0.8 dB 15-31.5 dB ± 1.00 dB or 2% 32-63 dB (whichever is greater)</pre>
Insertion Loss	8.0 dB maximum 2.0 dB typical @ 100 MHz 4.0 dB typical @ 6 GHz 5.5 dB typical @ 12.4 GHz 7.5 dB typical @ 18 GHz
RF Input Power	+24 dBm (operating - Input Side) +15 dBm (operating - Output Side) +25 dBm (no damage - Input Side) +16 dBm (no damage - Output Side)
Switching Speed	1 microsecond typical (after command is received and processed) (3 milliseconds typical processing time)
DC Supply	+12 Vdc (100-240 VAC AC/DC transformer included)

--CONTINUED--

# SPECIFICATION SHEET

## JFW MODEL 50BA-045-63

### BENCHTOP PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Manual Control	Momentary Lever Actuator Switch with 7-Segment LED Displays (tap to step, hold to jog) (jog speed range is 0-10) (jog speed set to 0 will disable all levers)
Remote Control	Ethernet (DHCP, TCP/IP, 10/100, up to 12 users) RS-232 (up to 115200 Baud)
Remote Commands	Attenuator Control Commands: Atten, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover System Commands: Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt, Jog Speed
RF Connector	SMA female
Operating Temperature Range	0°C to +50°C
Outline Drawing Number	092-9487 (50BA-045-63 SMA)

ECR/ECN	# DATE	REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
	02/03/2020		CLK 02/03/2020				
30836	12/21/2020	A	TRS 12/21/2020				