## SPECIFICATION SHEET JFW MODEL 50MS-291 MATRIX SWITCH

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range 700	-3000	MHZ
---------------------	-------	-----

Configuration 12 x 8 Blocking Solid-State Matrix Switch

(See block diagram 092-7180)

(Unused input ports are self-terminating) (Unused output ports are self-terminating)

(all ports are bi-directional)

(the ADMIN password is located on rear panel)

Startup/Default States

(configurable)

All ports off at startup (see MATRIX command)

DHCP enabled (see NET command)
4 Ethernet users (see NET command)
Prompts off (see PROMPT command)

All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users.

Enclosure Type 19 inch rack mount @ 6RU high

Impedance 50 Ohms nominal

VSWR 1.6:1 maximum 1.5:1 typical

Insertion Loss 14 dB maximum

Isolation Output to Output - 70 dB typical (Set to same input) - 60 dB minimum

Input to Output - 70 dB typical (Output OFF) - 60 dB minimum

Input to Input - 70 dB typical - 60 dB minimum

RF Input Power +20 dBm average

Switching Speed 20 microseconds

(after command is received and processed)
(3 milliseconds typical processing time)

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

## -- CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

## SPECIFICATION SHEET JFW MODEL 50MS-291 MATRIX SWITCH

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands Matrix Commands:

Matrix, Set Input, Set Output, Read Input, Read

Output, Read All Inputs, Read All Outputs, Read Matrix

Paths

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime,

Prompt

RF Connector N female

AC Supply 100-240 VAC @ 47-63 Hz

4 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-004, JFW #025-018

Temperature Ranges Operating: 0°C to +70°C

Storage: -55°C to +85°C

Physical Size See outline drawing 092-7179

ECR/ECN	# DATE	REV	APPR / DATE	ECR/ECN # DATE	REV APPR / DATE	
	12/27/2011		CLK 12/27/2011			_
21887	09/06/2012	A	TRS 09/06/2012			
24239	07/15/2015	В	TRS 07/15/2015			

Page 2 of 2 JFW FORM E-7-F REV F