SPECIFICATION SHEET JFW MODEL 50MS-304 MATRIX SWITCH

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency	Range	2-6	GHz
-----------	-------	-----	-----

Configuration 6 x 6 Non-Blocking Solid-State Matrix Switch

(See block diagram 092-7408)

(Unused input ports are self-terminating) (Unused output ports are self-terminating)

(all ports are bi-directional)

(the ADMIN password is located on rear panel)

Startup/Default States

(configurable)

All ports off at startup (see MATRIX command)

DHCP enabled (see NET command)
4 Ethernet users (see NET command)
Prompts off (see PROMPT command)

All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users.

Enclosure Type 19 inch rack mount @ 5RU high

Impedance 50 Ohms nominal

VSWR 1.5:1 typical 1.7:1 maximum

Insertion Loss 16.5 dB nominal @ 2GHz 18.5 dB nominal @ 6GHz

Isolation

Input to Input - 70 dB minimum
Input to Output - 70 dB minimum
Output to Output - 18 dB minimum
(If connected to same Input)
Output to Output - 70 dB minimum

(If connected to different Inputs)

RF Input Power +20 dBm maximum

Switching Speed 1 microsecond

(After command is received and processed)
(3 millisecond typical processing time)

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

--CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

SPECIFICATION SHEET JFW MODEL 50MS-304 MATRIX SWITCH

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands Matrix Commands:

Matrix, Set Input, Set Output, Read Input, Read

Output, Read All Inputs, Read All Outputs, Read Matrix

Paths

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime,

Prompt

RF Connectors SMA female

AC Supply 100-240 VAC @ 47-63 Hz

2 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-002, JFW #025-021

Temperature Ranges Operating: 0°C to +70°C

Storage: -55°C to +85°C

Physical Size See outline drawing 092-7407

ECR/ECN # D	DATE REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
07/	23/2012	BAC 07/23/2012				
24239 07/	15/2015 A	TRS 07/15/2015				

Page 2 of 2 JFW FORM E-7-F REV F