SPE	CIFICA	TION	SHEET
JFW	MODEL	50M	S-335
МАТІ	RIX SW	ITCH	

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency	Range	700-3000	MHz
-----------	-------	----------	-----

Configuration 8 x 16 Non-Blocking Solid-State Matrix Switch

(See block diagram 092-8363)

(Unused input ports are self-terminating) (Unused output ports are self-terminating)

(all ports are bi-directional)

(the ADMIN password is located on rear panel)

Startup/Default States

(configurable)

All ports off at startup (see MATRIX command)

DHCP enabled (see NET command)
4 Ethernet users (see NET command)
Prompts off (see PROMPT command)

All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users.

Enclosure Type 19 inch rack mount @ 6RU high

Impedance 50 Ohms nominal

VSWR 1.5:1 typical 1.8:1 maximum

Insertion Loss 15.5 dB typical @ 700MHz 18.5 dB typical @ 3000MHz

Isolation Output to Output - 30 dB typical (Set to same input) - 25 dB minimum

Output to Output

(Set to diff inputs) - 90 dB typical - 60 dB minimum

Input to Output - 90 dB typical - 60 dB minimum

Input to Input - 70 dB typical - 60 dB minimum

RF Input Power +20 dBm average

+27 dBm (no damage)

Switching Speed 20 microseconds

(after command is received and processed)
(3 milliseconds typical processing time)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

--CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

SPECIFICATION SHEET JFW MODEL 50MS-335 MATRIX SWITCH

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Commands Matrix Commands:

Matrix, Set Input, Set Output, Read Input, Read

Output, Read All Inputs, Read All Outputs, Read Matrix

Paths

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime,

Prompt

RF Connector N or SMA female

AC Supply 100-240 VAC @ 47-63 Hz

2 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-002, JFW #025-021

Temperature Ranges Operating: 0°C to +70°C

Storage: -55°C to +85°C

Physical Size See outline drawing 092-8167

ECR/ECN	# DATE	REV	APPR / DATE	ECR/ECN # DATE	REV APPR / DATE
	11/19/2014		BAC 11/19/2014		
25550	07/14/2015	А	TRS 07/14/2015		
30909	01/28/2021	В	TRS 01/28/2021		

Page 2 of 2 JFW FORM E-7-F REV F