SPECIFICATION SHEET JFW MODEL 50MS-460 MATRIX SWITCH

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

| Frequency Range | 350-6000 MHz | | |
|---------------------------------------|---|---|--|
| Configuration | 4 x 4 Non-Blocking Solid-State Matrix Switch (See block diagram 092-7494) (Unused input ports are self-terminating) (Unused output ports are self-terminating) (all ports are bi-directional) (the ADMIN password is located on rear panel) | | |
| Startup/Default States (configurable) | All ports off at startup (see MATRIX command) DHCP enabled (see NET command) 4 Ethernet users (see NET command) Prompts off (see PROMPT command) | | |
| | All of these default settings can be changed by user Unit can be configured for up to 12 Ethernet users. | | |
| Enclosure Type | 19 inch rack mount @ 3RU high | | |
| Impedance | 50 Ohms nominal | | |
| VSWR | 1.7:1 typical / 2.0:1 maximum | | |
| Insertion Loss | 9.4 dB typical @ 350 MHz 11.2 dB typical @ 3000 MHz 13.1 dB typical @ 6000 MHz | | |
| Isolation | Output to Output (Set to same input) | - 15 dB typical (350-500 MHz) - 14 dB minimum (350-500 MHz) - 25 dB typical (500-6000 MHz) - 20 dB minimum (500-6000 MHz) | |
| | Output to Output (Set to diff inputs) | - 75 dB typical - 60 dB minimum | |
| | Input to Output | - 75 dB typical - 60 dB minimum | |
| | Input to Input | - 75 dB typical - 60 dB minimum | |
| RF Input Power | +30 dBm (input ports) +27 dBm (output ports | | |
| Switching Speed | 10 microseconds typical (after command is received and processed) (3 milliseconds typical processing time) | | |

--CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

SPECIFICATION SHEET JFW MODEL 50MS-460 MATRIX SWITCH

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

Remote Commands Matrix Commands:

Matrix, Set Input, Set Output, Read Input, Read

Output, Read All Inputs, Read All Outputs, Read Matrix

Paths

System Commands:

Help, Identification, Store, Recall, Pause,

Net, Serial, Close, Disconnect, MOTD,

Date, Message, Restrict, IDENT, Name, Show Users,

Reboot, Uptime, Prompt

RF Connector N or SMA female

AC Supply 100-240 VAC @ 47-63 Hz

Temperature Ranges Operating: 0°C to +70°C

Storage: -55°C to +85°C

Physical Size See outline drawing: 092-9243 (SMA)

092-6835 (N)

| ECR/ECN # DATE | REV APPR / DATE | ECR/ECN # DATE | REV APPR / DATE |
|----------------|-----------------|----------------|-----------------|
| 04/15/2024 | BAC 04/15/2024 | | |

Page 2 of 2 JFW FORM E-7-F REV F