## SPECIFICATION SHEET JFW MODEL 50PA-1021 LC HANDOVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range 2-6 GHz

Configuration Dual 4 X 1 LC Handover Test System

(See block diagram 092-8696)
(all ports are bi-directional)
(limited fan-out configuration)

(the ADMIN password is located on rear panel)

Enclosure Type 19 inch rack mount @ 2RU high

Impedance 50 Ohms nominal

Attenuation Range 0-95 dB in 1 dB steps

Startup/Default States Attenuators to 95dB at startup (see ATTEN command)

(configurable)

DHCP enabled (see NET command)

4 Ethernet users (see NET command)

Prompts off (see PROMPT command)

All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users.

VSWR 1.6:1 maximum

Attenuation Accuracy ± 0.50 dB 1-7 dB

± 1.00 dB 8-11 dB
± 1.25 dB or 4% 12-95 dB
(whichever is greater)
(guaranteed monotonic)

Insertion Loss 22.5 dB maximum 21.5 dB typical

Power Divider Isolation 20 dB minimum

25 dB typical

RF Input Power +27 dBm (into Attenuator ports)

+33 dBm (into J1/J2 ports)

Switching Speed 4 microseconds typical

(after command is received and processed)
(3 milliseconds typical processing time)

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

## --CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

## SPECIFICATION SHEET JFW MODEL 50PA-1021 LC HANDOVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands Attenuator Control Commands:

Atten, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime,

Prompt

RF Connector N or SMA female

AC Supply 100-240 VAC @ 47-63 Hz

Operating Temperature Range 0°C to +50°C

Physical Size See outline drawing 092-7122

ECR/ECN	# DATE	REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
	08/25/2016		TRS 08/25/2016				
28159	10/06/2017	A	CLK 10/06/2017				

Page 2 of 2 JFW FORM E-7-F REV F