SPECIFICATION SHEET JFW MODEL 50PA-659 HANDOVER TEST SYSTEM	JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com
Frequency Range	100-1000 MHz
Configuration	6 x 6 Handover Test System (see block diagram 092-5931 for attenuator addressing) (all ports are bi-directional) (full fan-out i.e. every path has its own attenuator) (the ADMIN password is located on rear panel)
Enclosure Type	19 inch rack mount @ 8RU high
Impedance	50 Ohms nominal
Attenuation Range	0-127 dB in 1 dB steps
Startup/Default States (configurable)	Maximum attenuation (see ATTEN STARTUP command) DHCP enabled (see NET command) 4 Ethernet users (see NET USERS command) Prompts off (see PROMPT command)
VSWR	1.7:1 maximum < 1.5:1 typical
Insertion Loss	30.0 dB maximum 28.5 dB typical @ 1000 MHz
Attenuation Accuracy	± 0.5 dB or 2% of programmed (whichever is greater)
Isolation	Input to Input: 40 dB minimum Output to Output: 40 dB minimum
RF Input Power	+20 dBm
Switching Speed	5 microseconds typical (after command is received and processed) (3 milliseconds typical processing time)
AC Supply	100-240 VAC @ 47-63 Hz 4 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-004, JFW #025-018
Manual Control	20-Button Keypad and LCD display (IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)
Remote Control	Ethernet (DHCP, TCP/IP, 10/100, up to 12 users) RS-232 (up to 115200 Baud)

--CONTINUED--

SPECIFICATION SHEET JFW MODEL 50PA-659 HANDOVER TEST SYSTEM	JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com
Remote Commands	Attenuator Control Commands: Atten, Set Path, Read Path, Read All Paths, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover
	System Commands: Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt
RF Connector	SMA or N female
Temperature Range	0°C to +50°C
Physical Size	See outline drawing 092-5930

ECR/ECN # DAT	e rev	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
04/22	/2011	TRS 04/22/2011				
20598 09/09	/2011 A	TRS 09/09/2011				