### SPECIFICATION SHEET

JFW MODEL 50BA-012-95

## BENCHTOP PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range 30-3000 MHz Configuration Four individually controlled solid-state programmable attenuators Enclosure Type Mini-benchtop 50 Ohms nominal Impedance 0-95 dB in 1 dB steps Attenuation Range Startup/Default States Maximum attenuation (see ATTEN STARTUP command) DHCP enabled (see NET command) (configurable) 4 Ethernet users (see NET USERS command) Prompts off (see PROMPT command) Jog speed 5 (see JOG SPEED command) 2.0:1 maximum VSWR 30-700 MHz 1.6:1 maximum 700-3000 MHz ± 0.50 dB 1-7 dB Attenuation Accuracy ± 1.00 dB (guaranteed monotonic) 8-11 dB ± 1.25 dB or 3% 12-95 dB (whichever is greater) 5.5 dB maximum Insertion Loss 5.0 dB typical RF Input Power\* +27 dBm average +33 dBm (no damage) Switching Speed 4 microseconds typical (after command is received and processed) (3 milliseconds typical processing time) DC Supply +12 Vdc (100-240 VAC AC/DC transformer included) Manual Control Four Momentary Lever Actuator Switches with 7-Segment LED Displays (tap to step, hold to jog) (jog speed range is 0-10) (jog speed set to 0 will disable all levers) Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users) RS-232 (up to 115200 Baud)

# --CONTINUED--

#### SPECIFICATION SHEET

## JFW MODEL 50BA-012-95

## BENCHTOP PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Attenuator Control Commands: Remote Commands Atten, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover System Commands: Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime, Prompt, Jog Speed RF Connector SMA female Operating Temperature Range 0°C to +50°C Physical Size See outline drawing 092-8150

\* Units shipped before 10/5/2017 (date code 1740) are only rated at +20dBm maximum. The JFW date code is a four digit code (YYWW) that follows the six digit serial number. For example date code 1908 is the 8th week of 2019.

E	ECR/ECN	# DATE	REV	APPR / DATE	ECR/ECN	# DATE	REV	APPR / DATE
_		03/04/2013		CLK 03/04/2013	28159	10/05/2017	С	CLK 10/05/2017
	23463	11/19/2013	A	CLK 11/19/2013	29857	10/02/2019	D	TRS 10/02/2019
	24239	11/14/2014	В	TRS 11/14/2014				