#### SPECIFICATION SHEET

### JFW MODEL 50BA-042-63

# BENCHTOP PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range 100 MHz-18 GHz

Configuration One solid-state programmable attenuator

Enclosure Type Mini-benchtop

Impedance 50 Ohms nominal

Attenuation Range 0-63 dB in 0.5 dB steps

Startup/Default States

(configurable)

Maximum attenuation (see ATTEN STARTUP command)

DHCP enabled (see NET command)

4 Ethernet users (see NET USERS command)

Prompts off (see PROMPT command)
Jog speed 5 (see JOG SPEED command)

VSWR 2.2:1 maximum

< 1.4:1 typical 0.1-6 GHz < 1.8:1 typical 6-18 GHz

Attenuation Accuracy  $\pm$  0.3 dB  $\pm$  0.5-3.5 dB  $\pm$  0.6 dB  $\pm$  4-14.5 dB

± 0.6 dB 4-14.5 dB ± 1.00 dB or 3% 15-63 dB (whichever is greater)

Insertion Loss 8.0 dB maximum

2.0 dB typical @ 100 MHz 4.0 dB typical @ 6 GHz 5.5 dB typical @ 12.4 GHz 7.5 dB typical @ 18 GHz

RF Input Power +24 dBm (operating - Input Side)

+15 dBm (operating - Output Side) +25 dBm (no damage - Input Side) +16 dBm (no damage - Output Side)

Switching Speed 1 microsecond typical

(after command is received and processed)
(3 milliseconds typical processing time)

DC Supply +12 Vdc

(100-240 VAC AC/DC transformer included)

Manual Control Momentary Lever Actuator Switch with

7-Segment LED Display (tap to step, hold to jog) (jog speed range is 0-10)

(jog speed set to 0 will disable all levers)

## -- CONTINUED --

Page 1 of 2 JFW FORM E-7-F REV F

### SPECIFICATION SHEET

### JFW MODEL 50BA-042-63

### BENCHTOP PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

Remote Commands Attenuator Control Commands:

Atten, Set Attenuator, Read Attenuator, Fade

Attenuator

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message,

Restrict, IDENT, Name, Show Users, Reboot,

Uptime, Prompt, Jog Speed

SMA female RF Connector

Operating Temperature Range

Outline Drawing Number

 $0^{\circ}C$  to  $+50^{\circ}C$ 

092-9486 (50BA-042-63 SMA)

ECR/ECN	# DATE	REV	APPR / DATE	ECR/ECN # DATE	REV APPR / DATE
	02/03/2020		CLK 02/03/2020		
30836	12/21/2020	A	TRS 12/21/2020		
33272	03/28/2024	В	CLK 03/28/2024		

Page 2 of 2 JFW FORM E-7-F REV F