## SPECIFICATION SHEET JFW MODEL 50PMA-106 TRANSCEIVER TEST SYSTEM

(configurable)

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Frequency Range 2-6 GHz

Configuration 4 Port Transceiver Test System

(see block diagram 092-6984 for attenuator addressing)

(all ports are bi-directional)

(full fan-out i.e. every path has its own attenuator)

(the ADMIN password is located on rear panel)

Enclosure Type 19" rack mount @ 2RU high

Impedance 50 Ohms nominal

Attenuation Range 0-95 dB in 1 dB steps

Startup/Default States Attenuators to 95dB at startup (see ATTEN command)

DHCP enabled (see NET command)
4 Ethernet users (see NET command)
Prompts off (see PROMPT command)

VSWR 1.7:1 maximum 1.5:1 typical

1.0.1 cyprous

Attenuation Accuracy  $\pm$  0.5 dB  $\pm$  1-7 dB  $\pm$  1.0 dB  $\pm$  1.1 dB

± 1.25 dB or 4% 12-95 dB
(whichever is greater)
(guaranteed monotonic)

Insertion Loss 29 dB maximum

23 dB typical @ 2 GHz 27 dB typical @ 6 GHz

Power Divider Isolation 20 dB minimum

23 dB typical

RF Input Power 1 Watt average

Switching Speed 4 microseconds (after command received and processed)

(3 milliseconds typial processing time)

Manual Control 20-Button Keypad and LCD display

(IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Remote Control Ethernet (DHCP, TCP/IP, 10/100, up to 12 users)

RS-232 (up to 115200 Baud)

## --CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

## SPECIFICATION SHEET JFW MODEL 50PMA-106 TRANSCEIVER TEST SYSTEM

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands Attenuator Control Commands:

Atten, Set Path, Read Path, Read All Paths, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover, Set 2nd 32dB Bit

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime,

Prompt

RF Connector SMA female

AC Supply 100-240 VAC @ 47-63 Hz

2 Amp 5x20mm "Slo-Blo" AC fuse Littelfuse #215-002, JFW #025-021

Operating Temperature Range 0°C to +50°C

Physical Size See outline drawing 092-7961

ECR/ECN	# DATE	REV	APPR / DATE	ECR/ECN # DATE	REV APPR / DATE
	12/15/2015		TRS 12/15/2015		
28159	10/05/2017	A	CLK 10/05/2017		
33906	01/30/2025	В	TRS 01/30/2025		

Page 2 of 2 JFW FORM E-7-F REV F