SPECIFICATION SHEET

JFW MODEL 75PA-076

PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

DC-2150 MHz Frequency Range

Configuration Two individually controlled electro-mechanical

programmable attenuators

75 Ohms nominal Impedance

Attenuation Range 0-63 dB in 1 dB steps

Startup/Default States

(configurable)

Maximum attenuation (see ATTEN command)

DHCP enabled (see NET command)

4 Ethernet users (see NET USERS command)

Prompts off (see PROMPT command)

All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users

Attenuators to 63dB at startup (see ATTTEN command)

1.6:1 maximum **VSWR**

1-31 dB ± 0.6 dB or 3% 32-63 dB ± 4% Attenuation Accuracy

(quaranteed monotonic)

(whichever is greater)

Insertion Loss 1.25 dB typical @ 1000MHz

2.25 dB typical @ 2150MHz

2.75 dB maximum DC-2150MHz

+27 dBm average RF Input Power

Switching Speed 6 milliseconds typical

> (after command is received and processed) (3 milliseconds typical processing time)

100-240 VAC @ 47-63 Hz AC Supply

Manual Control 20-Button Keypad and LCD display

> (IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad)

Ethernet (DHCP, TCP/IP, 10/100, up to 12 users) Remote Control

RS-232 (Up to 115200 Baud)

--CONTINUED--

Page 1 of 2 JFW FORM E-7-F REV F

SPECIFICATION SHEET

JFW MODEL 75PA-076

PROGRAMMABLE ATTENUATOR ASSEMBLY

JFW Industries, Inc. Phone: 317-887-1340 sales@jfwindustries.com www.jfwindustries.com

Remote Commands

Attenuator Control Commands:

Atten, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block,

Set Block, Read

Block, Read All Blocks, Fade Block, Variable Block

Handover

System Commands:

Help, Identification, Store, Recall, Pause, Net, Serial, Close, Disconnect, MOTD, Date, Message, Restrict, IDENT, Name, Show Users, Reboot, Uptime,

Prompt

RF Connector

F female

Operating Temperature Range

0°C to +50°C

Physical Size

See outline drawing 092-7915

ECR/ECN	# DATE	REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
	01/27/2014		BAC 01/27/2014				
25583	07/27/2015	A	BAC 07/27/2015				

Page 2 of 2 JFW FORM E-7-F REV F